



Precision thermometer
for Pt100 4-wire temperature probes

as of version 1.8

operating manual

GMH 3750



GMH 3700 Series
Pt100 Thermometer
Hochpräzision / High-Precision



WEEE-Reg.-Nr. DE 93889386

CONTENTS

1	GENERAL NOTE	3
2	SAFETY	3
2.1	INTENDED USE	3
2.2	SAFETY SIGNS AND SYMBOLS	3
2.3	SAFETY GUIDELINES	3
3	PRODUCT SPECIFICATION	4
3.1	SCOPE OF SUPPLY	4
3.2	OPERATION AND MAINTENANCE ADVICE	4
4	HANDLING	5
4.1	DISPLAY	5
4.2	BASIC OPERATION	5
4.3	CONNECTIONS	5
4.4	POP-UP CLIP	6
5	START OPERATION	7
6	CONFIGURATION	7
7	REMARKS TO SPECIAL FEATURES	8
7.1	DISPLAY RESOLUTION	8
7.2	AVERAGE FILTER („T.AUG“)	8
7.3	ALARM („AL.“)	8
7.4	USER SENSOR CURVE ('LIN USER')	9
7.5	REAL TIME CLOCK („CLOC“)	9
8	OPERATION OF LOGGER	9
8.1	STORING SINGLE MEASUREMENTS („FUNC-STOR“)	9
8.2	AUTOMATIC RECORDING WITH SELECTABLE CYCLE TIME „FUNC CYCL“	10
9	OUTPUT	11
9.1	SERIAL INTERFACE	11
9.2	ANALOGUE OUTPUT – SCALING WITH DAC.0 AND DAC.1	12
10	INPUT ADJUSTMENT	12
10.1	ZERO DISPLACEMENT ('OFFSET')	12
10.2	SCALE CORRECTION ('SCALE')	12
10.3	CALIBRATION SERVICES	12
11	PROBE CONNECTION	12
11.1	4-WIRE CONNECTIONS	12
11.2	2- OR 3-WIRE CONNECTIONS	12
11.3	4-POLIGER MINI DIN PLUG	13
12	SOME BASICS OF PRECISION TEMPERATURE MEASURING	13
13	FAULT AND SYSTEM MESSAGES	14
14	RESHIPMENT AND DISPOSAL	15
14.1	RESHIPMENT	15
14.2	DISPOSAL INSTRUCTIONS	15
15	SPECIFICATIONS	16

1 General Note

Read this document carefully and get used to the operation of the device before you use it. Keep this document within easy reach near the device for consulting in case of doubt.

Mounting, start-up, operating, maintenance and removing from operation must be done by qualified, specially trained staff that have carefully read and understood this manual before starting any work.

The manufacturer will assume no liability or warranty in case of usage for other purpose than the intended one, ignoring this manual, operating by unqualified staff as well as unauthorized modifications to the device. The manufacturer is not liable for any costs or damages incurred at the user or third parties because of the usage or application of this device, in particular in case of improper use of the device, misuse or malfunction of the connection or of the device.

2 Safety

2.1 Intended Use

The GMH 3750 is a precision thermometer for the measurement of the temperature with exchangeable 4-wire Pt100 temperature sensors. With high resolution and precision temperature values can be measured from -200 to 850 °C.

The device is to be protected against wetness and soiling and has to be stored and operated only within the permissible environmental conditions and connection data (see "Specification").

2.2 Safety signs and symbols

Warnings are labelled in this document with the followings signs:



Caution! This symbol warns of imminent danger, death, serious injuries and significant damage to property at non-observance.



Attention! This symbol warns of possible dangers or dangerous situations which can provoke damage to the device or environment at non-observance.



Note! This symbol point out processes which can indirectly influence operation or provoke unforeseen reactions at non-observance.

2.3 Safety guidelines

This device has been designed and tested in accordance with the safety regulations for electronic devices. However, its trouble-free operation and reliability cannot be guaranteed unless the standard safety measures and special safety advises given in this manual will be adhered to when using the device.

1. Trouble-free operation and reliability of the device can only be guaranteed if the device is not subjected to any other climatic conditions than those stated under "Specification".

If the device is transported from a cold to a warm environment condensation may cause in a failure of the function. In such a case make sure the device temperature has adjusted to the ambient temperature before trying a new start-up.

2. If there is a risk whatsoever involved in running it, the device has to be switched off immediately and to be marked accordingly to avoid re-starting.



Operator safety may be a risk if:

- there is visible damage to the device
- the device is not working as specified
- the device has been stored under unsuitable conditions for a longer time.

In case of doubt, please return device to manufacturer for repair or maintenance.

3. When connecting the device to other devices the connection has to be designed most thoroughly as internal connections in third-party devices (e.g. connection GND with protective earth) may lead to undesired voltage potentials that can lead to malfunctions or destroying of the device and the connected devices.



DANGER

This device must not be run with a defective or damaged power supply unit.
Danger to life due to electrical shock!

4. Do not use these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury or material damage. Failure to comply with these instructions could result in death or serious injury and material damage.



DANGER

5. This device must not be used at potentially explosive areas! The usage of this device at potentially explosive areas increases danger of deflagration, explosion or fire due to sparking.



DANGER

6. This device is not constructed for use in medical applications.



DANGER

3 Product Specification

3.1 Scope of supply

The scope of supply includes:

- device with 9V battery block
- Operation manual

3.2 Operation and maintenance advice

• Battery operation

If 'bAt' is shown in the lower display the battery has been used up and needs to be replaced. However, the device will operate correctly for a certain time. If 'bAt' is shown in the upper display the voltage is too low to operate the device; the battery has been completely used up.



The battery has to be taken out, when storing device above 50 °C.

**We recommend taking out battery if device is not used for a longer period of time.
After recommissioning the real-time clock has to be set again.**

• Mains Operation with power supply



ATTENTION

When using a power supply please note that operating voltage has to be 10.5 to 12 V DC. Do not apply overvoltage!! Cheap 12V-power supplies often have excessive no-load voltage. We, therefore, recommend using regulated voltage power supplies.

Trouble-free operation is guaranteed by our power supply GNG10/3000.

Prior to connecting the power supply to the mains make sure that the operating voltage stated at the power supply is identical to the mains voltage.

- Treat device and sensor carefully. Use only in accordance with above specification. (do not throw, hit against etc.). Protect plug and socket from soiling.
- To disconnect temperatur sensor plug do not pull at the cable but at the plug. When connecting the probe the plug will slide in smoothly if plug is entered correctly.
- **Selection of Output-Mode:** The output can be used as serial interface or as analogue output. This choice has to be done in the configuration menu.

4 Handling

4.1 Display




- 1 **Maindisplay:** Currently measured temperature
 - 2 **Secondary display:** Display of min, max or hold values
- Special display elements:**
- 3 **Min/Max/Hold:** shows if a min., max. or hold value is displayed in the auxiliary display
 - 4 **“Offset“ arrow:** indicates that zero point offset is activated
 - 5 **„Corr“ arrow:** indicates that a scale correction is activated
 - 6 **„Logg“ arrow:** Shown if logger function is selected, flashes if cyclic logger is running
 - 7 **„Alarm“ arrow:** Flashes if alarm is present

4.2 Basic Operation



On / Off



min/max at measure:

- press short: shows the min./max. value
- press again: hides min./max. value
- press 2 sec.: clears particular value



Function only during configuration:
Selection of menu-parameter



Set/Menu:

- press short: invokes configuration menu

Store/Quit:


- press short: hold-function, the last measuring value will be held in the secondary display.



at active logger: invokes logger functions

at menu: acknowledge setting, return to measurement

4.3 Connections



Output: Connection for el. Isolated interface adapter or for analog output (please refer to chapter 9)


Probe connection: 4 pole Mini-DIN-Socket, for Pt100 4-wire probes

Power supply: the mains adapter socket is located at the left side of the device.

4.4 Pop-up clip


Handling:

- Pull at label "open" in order to swing open the pop-up clip.
- Pull at label "open" again to swing open the pop-up clip further.




Function:

- The device with a closed pop-up clip can be plainly laid onto a table or attached to a belt, etc.
- The device with pop-up clip at position 90° can be set up on a table, etc.
- The device with pop-up clip at position 180° can be suspended from a screw or the magnetic holder GMH 1300.



5 Start Operation

Connect temperature probe, turn on device via  key.



After segment test the device displays some configuration:

- If the logger function is not off, the time of the integrated clock will shortly be displayed.
- If a **zero point adjustment** was carried out, the display shows shortly „nuLL Corr“.

After changing the battery the clock-setting menu is activated automatically („CLOC“). Check the clock and adjust, if necessary (p.r.t. chapter 6).

After that, the device is ready for measuring.

6 Configuration



To change device settings, press **Menu** (key 4) for 2 seconds. This will call the configuration menu (main display: „SEt“ or “rEAd LoGG”).













Pressing key **Menu** changes between the menus, pressing **▶** (key 3) jumps to the referring parameters, which can be selected with key **▶** (key 3).

The parameters can be changed with **▲** (key 2) or **▼** (key 5).

Pressing **Menu** again jumps back to the main configuration menu and saves the settings.

Quit (key 6) finishes the configuration and returns to standard measuring operation.

Menu(*1)	Parameter/Values(2*)	Meaning	p.r.t.
Menu	▶ ▲ or ▼		
	Read Logg: single value-logger read out (Only when data existing! Please refer to chapter 12)		8
	Set Configuration: Generic Settings		
Unit	°C:	All temperature values are in degrees Celsius	*
	°F:	All temperature values are in degrees Fahrenheit	
RES	0.1° / 0.01°:	Resolution 0.1° / 0.01°	* 7.1
	Auto:	Resolution is selected automatically	
Lin	E.751	characteristic curve according to EN60751	* 7.4
	USER	User sensor curve (Predefined to EN60751 values, changeable by software GMHKonfig)	
OFF5	-2.50...2.50°C / -4.50...4.50°F	Zero correction	* 10.1
	oFF:	Zero displacement inactive (=0.0°)	
SCAL	-2.000...2.000:	Scale correction [in %]	* 10.2
	oFF:	Scale correction factor inactive (=0.000)	
LAUF	1...30:	Average filter (period in seconds)	* 7.2
	oFF:	Average filter inactive	
P.oFF	1...120	Power-off delay in minutes. Device will be automatically switched off as soon as this time has elapsed if no key is pressed or no interface communication takes place	
	oFF	Power-off function inactive (continuous operation)	
Out	oFF:	No output function	9
	SEr:	Output is serial interface	
	dAC:	Output is analogue output	
Adr.	01,11..91	Base address of device for interface communication	9.1
dA.C.O	-200..850°C / -328...1562°F	Zero point of analogue output: Temperature at which the analogue output potential should be 0V	9.2

		-200..850°C / -328...1562°F	Scale of analogue output : Temperature value at which the analogue output potential should be 1V		9.2
Set Alarm: Setting of Alarm Function					
		On / No.So	Alarm on with horn-sound / Alarm on without horn-sound		7.3
		OFF	no alarm function		
		-200°C ...AL.Hi	Min alarm rail (not when AL. oFF)		
		AL.Lo ... 850°C	Max alarm rail (not when AL. oFF)		
Set Logger: Setting of Logger Function					
		CYCL	Cyclic: logger function cyclic logger	*	8
		Stor	Store: logger function individual value logger		
		OFF	No logger function		
	0:01... 60:00	Cycle time of cyclic logger [minutes:seconds]	*	8	
Set Clock: Einstellen der Echtzeituhr					
		HH:MM	Clock: Setting of time hours:minutes		7.4
		YYYY	Year		
		TT.MM	Date: day.month		

(*) **If the logger memory contains data already, the menus/parameters marked with (*) can not be invoked! If these should be altered the logger has to be stopped and the memory has to be cleared before!**

Hint: Restoring of ex-works settings

The settings will be set to the settings ex works, if keys 'Set' and 'Store' are pressed simultaneously for more than 2 seconds.

7 Remarks To Special Features

7.1 Display Resolution

Standard setting: 'Auto', i.e. the device automatically switches over to the optimum resolution between .01° and 0.01°.

If temperatures to be measured are near the switching threshold, a fixed resolution may be better, e.g. for easy manual recording. In such a case please set the optimum resolution to the desired value.

7.2 Average filter („t.AuG“)

The filter forms the arithmetic floating average over the entered time. The displayed value will be correspondingly slower in this case.

7.3 Alarm („AL.“)

There are three possible settings:

Alarm off (AL. oFF), on with horn sound (AL. on), on without horn sound (AL. no.So).

Following conditions will display an alarm, when the function is activated (on or no.So):

- Value is below lower (AL. Lo) or above upper alarm rail (AL.Hi).
- Sensor error
- Low battery (bAt)
- Err.7: System error (always with sound)

In case of an alarm and when polling the interface the "prio"-flag is set in the returned message.

7.4 User Sensor Curve ('Lin USER')

By means of this function besides the standard conversion of resistance to temperature following EN60751(Lin E.751) also other curves can be used. The user sensor curve can be read and edited by the configuration software GMHKonfig. The standard setting ex works is also set to the EN60751 data. The curve is defined by a table with two columns (input resistance [Ohm]/output temperature [°C]) with 50 rows. Info: the sensor curve following EN60751 uses the international temperature scale ITS90 and following formulas:

Temperatures < 0°C:

$$R_{\text{neg}}(T) := 100 \cdot [1 + 3.9083 \cdot 10^{-3} \cdot T - 5.775 \cdot 10^{-7} \cdot T^2 - 4.183 \cdot 10^{-12} \cdot (T - 100) \cdot T^3]$$

Temperatures >= 0°C:

$$R_{\text{pos}}(T) := 100 \cdot (1 + 3.9083 \cdot 10^{-3} \cdot T - 5.775 \cdot 10^{-7} \cdot T^2)$$

Please notice: Temperature measurements with the user sensor curve are allowed only within the temperature range, which has been used to generate the user sensor curve. Measuring with activated user sensor curve beyond the checked temperature range may lead to larger errors. Therefore the sensor curve acc. to EN 60751 (Lin E.751) has to be used for temperature measurements beyond the checked temperature range.

7.5 Real Time Clock („CLOC“)

The real time clock is used for the logger function: Recorded values are also containing the point of time, when they were measured. Please check the settings when necessary.

If the battery was replaced the referring menu ‚CLOC‘ will automatically be started

8 Operation Of Logger

The device supports two different logger functions:

„Func-Stor“: manual recording via keypress “Store” (key 6).

„Func-CYCL“: automatic recording with the selected recording interval/cycle

The logger records 1 measurement result each time

The data set consists of: - measuring value at time of recording
 - time and date of recording


For the read out and evaluation of the data the software GSOF3050 (V1.7 or higher) has to be used. The software also allows easy configuration and starting of the logger.


When the logger is activated (Func Stor or Func CYCL) the hold function is no longer available, key 6 is solely used for the operation of the logger functions.

8.1 Storing Single Measurements („Func-Stor“)

a) Record Measuring:



If the logger function “Func Stor” was activated (see chapter 6“Configuration”), up to 99 measuring data sets can be recorded manually.


 **Press shortly:** Data set will be recorded (“St. XX” will be shown shortly. XX is the number of the data set)

If the logger memory is full, the display will show: 

b) Viewing Recorded Measurements:


Stored data sets can be either read out via PC Software GSOF3050, or be viewed in the display directly.

 **Press for 2 seconds:** The display will show: 

Please note: ”rEAd Logg” only appears, if there are already data stored! If memory is empty, the configuration menu  will show.



Press shortly: Changing between measuring value and date+time of data set



Changing between the data sets



Exit logger data display

c) Clear recorded measurements:

If there are already data sets stored, these can be deleted via the store key:

Store
Quit Press for 2 seconds: Calling of clear-Menu

Change selection by: **max** or **min** :

$\begin{matrix} [Lr \\ no \end{matrix}$ Clear nothing (cancel menu)

$\begin{matrix} [Lr \\ ALL \end{matrix}$ Clear all recordings

$\begin{matrix} [Lr \\ LAST \end{matrix}$ Clear the last recording

Store
Quit Stores the settings

8.2 Automatic Recording With Selectable Cycle Time „Func CYCL“

If the logger function “Func CYCL” was activated (see chapter 6 “Configuration”), and the logger was started, it automatically records data sets at intervals of the selected logger cycle time. The logger cycle time is selectable from 1s to 60min (see chapter 6 “Configuration”).

Max. number of measurements: 16384

a) Starting a recording:

Store
Quit press for 2 seconds: the recording will be started.

Each recording is signaled with a short display of ‘St.XXXXX’. XX is the number of the data set.

If the logger memory is full, the display will show $\begin{matrix} L066 \\ FULL \end{matrix}$

b) Stop the recording:

Store
Quit Press for 2 seconds: If a recording is running, the Stop menu will be shown

Change selection by: **max** or **min** :

$\begin{matrix} StOp \\ no \end{matrix}$ Do not stop the recording

$\begin{matrix} StOp \\ YES \end{matrix}$ Stop the recording

Store
Quit Stores the settings

Note: *If you try to switch off the instrument in the cyclic recording operation, You will be asked automatically if the recording should be stopped.*

The device can only be switched off after the recording has been stopped!

The Auto-Power-Off-function is deactivated during recording!

c) Clear recorded measurements:

Store
Quit Press for 2 seconds: If logger data are present and the recording was stopped, the clear menu will be shown

Change selection by: **max** or **min** :

$\begin{matrix} [Lr \\ no \end{matrix}$ Clear nothing
(cancel menu)

$\begin{matrix} [Lr \\ ALL \end{matrix}$ Clear all recordings

Store
Quit Stores the settings

9 Output

The output can be used as serial interface (for USB 3100, USB 3100 N, GRS 3100 or GRS 3105 interface adapters) or as analogue output (0-1V).

If none of both is needed, we suggest to switch the output off, because battery life then is extended.

9.1 Serial Interface

By means of the serial interface and a suitable electrically isolated interface adapter (USB 3100, USB 3100 N, GRS 3100 or GRS 3105) the device can be connected to a computer for data transfer.

With the GRS 3105 up to 5 devices of the GMH3xxx- series can be connected to one interface (see also manual of GRS 3105). As a precondition the base addresses of all devices must not be identical, make sure to configure the base addresses accordingly (refer menu point "Adr." in chapter 6).

To avoid transmission errors, there are several security checks implemented e.g. CRC.

The following standard software packages are available for data transfer:

- **GSOFT3050:** Operating and evaluation software for instruments with integrated logger function
- **EBS20M/ -60M:** 20- / 60-channel software to record and display the measuring values
- **GMHKonfig:** Software for a comfortable configuration of the device (e.g. freeware)

In case you want to develop your own software we offer a **GMH3000-development package** including

- an universally applicable 32bit Windows functions library ('GMH3000.DLL') with documentation that can be used by all 'serious' programming languages.
- Programming examples for Visual Studio 2010 (C#, C++), Visual Basic 6.0™, Delphi 1.0™, Testpoint™, Labview™

In addition to the operation at a PC the device can be operated with the **GAM3000-device**, to use the alarm function for simple supervision and controlling applications. Just connect a GAM3000 to the interface, activate the alarm function of the GMH and the relays output is operating.

Supported interface functions:

code	name / function	code	name / function
0	Read nominal values	201	Read max. display range
3	Read system status	202	Read unit of display
6	Read min. values	204	Read decimal point of display
7	Read max values	208	Read channel count
12	Read ID-no	214	Read scale correction
22	Read min. alarm rail	215	Set scale correction
23	Read max. alarm rail	216	Read zero displacement
32	Read configuration flag Alarm function: 1, Alarm horn: 3 BitLoggerOn: 50, BitCyclicLogger: 51	217	Set zero displacement
		222	Read power – off time
		223	Set power – off time
102	Set min. alarm rail	224	Logger: read data cyclic logger
103	Set max. alarm rail	225	Logger: read cycle time (LoGG - CYCL)
160	Set configuration flag (see 32)	226	Logger: set cycle time (LoGG - CYCL)
174	Delete min. value	227	Logger: start recording
175	Delete max. value	228	Logger: read # of data
176	Read min. measuring range	229	Logger: read status
177	Read max. measuring range	231	Logger: read stop time
178	Read measuring range unit	233	Read real time clock (CLOC)
179	Read measuring range decimal point	234	Set real time clock (CLOC)
180	Read measuring type	236	Read logger memory size
194	Set display unit	240	Reset
199	Read measuring type in display	254	Read program identification
200	Read min. display range	260	Logger: read data manual logger

Note: *The measuring and display range values read via interface are always in the selected display unit (°C/°F)!*

9.2 Analogue Output – Scaling with DAC.0 and DAC.1

Note: Analogue output can not be used during logger recordings

With the DAC.0 and DAC.1 values the output can be rapidly scaled to your efforts.


Keep in mind not to connect low-resistive loads to the output, otherwise the output value will be wrong and battery life is decreased. Loads above ca 10kOhm are uncritical.

If the display exceeds the value set by DAC.1, then the device will apply 1V to the output

If the display falls below the value set by DAC.0, then the device will apply 0V to the output

In case of an error (Err.1, Err.2, no sensor, etc.) the device will apply slightly above 1V to the output.

plug wiring:



Attention!

the 3rd contact has to be left floating!
Only stereo plugs are allowed!

10 Input Adjustment

10.1 Zero Displacement ('Offset')

The zero displacement is used to adjust the measuring display for probe deviations.

$$\text{temperature displayed} = \text{temperature measured} - \text{offset}$$

Standard setting: 'off' = 0.0°, i.e. no zero displacement will be carried out. Together with the scale correction (see below) this factor is mainly used to compensate for sensor deviations.

Unless the factor is set to 'off', the offset arrow in the display shows an active zero displacement.*)

10.2 Scale Correction ('Scale')

The scale correction is used to adjust the measuring display for probe deviations. (factor is in %):

$$\text{displayed temperature}[^{\circ}\text{C}] = \text{measured temperature}[^{\circ}\text{C}] * (1 + \text{Scal}/100)$$

$$\text{or: displayed temperature}[^{\circ}\text{F}] = (\text{measured temperature } [^{\circ}\text{F}] - 32^{\circ}\text{F}) * (1 + \text{Scal}/100) + 32^{\circ}\text{F}$$

Standard setting: 'off' = 0.000, i.e. temperature is not corrected.

Unless the factor is set to 'off', the Corr arrow in the display shows an active scale correction.*)

*) *The standard curve (Lin E.751) and the user sensor curve (Lin USEr) possess separate correction settings.*

10.3 Calibration Services

Calibration certificates – DKD-certificates – other certificates:

If device should be certificated for its accuracy, it is the best solution to return it to the manufacturer.

Only the manufacturer is capable to do efficient recalibration if necessary to get results of highest accuracy!

11 Probe Connection

11.1 4-wire connections

The device is constructed and optimised for the connection of a **Pt100 4-wire probe** via 4 pole Mini-Din connectors.

4-wire connection





Figure shows upon probe jack pins

11.2 2- or 3-wire connections


It is also possible to connect a **3- or 2-wire probe** to the device. Please observe that in consequence of the cable and contact resistance an increased measuring fault will occur.

The connection of these probes should be carried out as follows:

3-wire connection



2-wire connection



11.3 4-pole Mini DIN plug

It is also possible to attach a 4-pin mini-DIN plug with lock for self-assembly. Article: MINIDIN 4S.

12 Some Basics Of Precision Temperature Measuring

Probe Precision/Device Precision

The device is very precise (please refer to technical data).

To be able to use this high precision, the connected temperature probe has to be as precise as possible, too.


The following precision classes are available as a standard at reasonable prices (Platinum resistor thermometers according to EN60751):

Tolerance class	Norm	max. deviation in Kelvin
B	IEC 751 / EN 60751	$\pm (0,30 + 0,00500 \cdot \text{temperature})$
A	IEC 751 / EN 60751	$\pm (0,15 + 0,00200 \cdot \text{temperature})$
AA (= 1/3 B)	IEC 751 / EN 60751	$\pm (0,10 + 0,00167 \cdot \text{temperature})$
1/10 B (= 1/10 B)	none	$\pm (0,03 + 0,00050 \cdot \text{temperature})$


The range of validity depends on the design of the sensor. Wire wound sensors allow wider temperature ranges than economic thin film sensors (further restrictions may result from product-specific properties, such as cables or connection technology)

Tolerance class	wire wound	thin film
B	-196 to +600 °C	-50 to +500 °C
A	-100 to +450 °C	-30 to +300 °C
AA (= 1/3 B)	-50 to +250 °C	0 to +150 °C
1/10 B (= 1/10 B)		-50 to 100 °C

Error band for Pt 100 thin film sensors:



Error band for wire wound Pt 100 sensors:



For applications demanding higher precision than given by these classes we suggest to adjust the device to the used probe or to get a DAkkS or ISO calibration certificate for the device combined with the probe.

Attention: if an adjusted or calibrated probe is replaced, also the adjustment or calibration certificate has to be renewed to maintain the referring overall precision! Be careful when buying third party temperature probes: Besides the standard EN 60751 there are some other obsolete or unusual standards on the market. If such a probe has to be connected, the user sensor curve (have a look to the referring chapter) can be used to adjust the instrument!

4-Wire-Measuring

When using resistance thermometers as the Pt100 a quite large measuring error can be caused by inadequate cables and connections. Using 4wire measuring avoids this kinds of errors mainly caused by unwanted resistances. It is suggested to use suitable probes and extensions only.

Heat loss caused by probe construction:

Especially when measuring temperatures which deviate very much from the ambient temperature, measuring errors often occur if the heat loss caused by the probe is not considered. When measuring fluids therefore the probe should be emerged sufficiently deep and be stirred continuously. When measuring gases the probe should also emerge as deep as possible in the gas to be measured (e.g. when measuring in channel/pipes) and the gas should flow around the probe at sufficient flow.

Measuring surface temperature

If temperature of the surface of an object has to be measured, one should pay attention especially when measuring hot (or very cold) surfaces, that the ambient air cools (or heats) the surface. Additionally the object will be cooled (or heated) by the probe or the probe can have a better heat flow to the ambient temperature as to the objects surface. Therefore specially designed surface probes should be used. The measuring precision depends mainly on the construction of the probe and of the physics of the surface itself. If selecting a probe try to choose one with low mass and heat flow from sensor to handle. Thermally conductive paste can increase the precision in some cases.

Allowable temperature range of probes

Pt100 Sensors are defined over a wide temperature range. Depending on probe materials and sort of sensor (e.g. hybrid sensors, wire wound resistors...) the allowable temperature ranges have to be considered. Exceeding the ranges at least causes a wrong measuring, it may even damage the probe permanently!

Often it also has to be considered, that the temperature range is just valid for the probe tube, (plastic-) handles can't stand the same high temperatures. Therefore, the tube length should be selected long enough, that temperature keeps low at the handle.



Self-heating

The measuring current of the instrument is just 0.3mA. The resulting in practice sensor heating even small sensor elements can be neglected.

Cooling by evaporation

When measuring air temperature the probe has to be dry. Otherwise, the cooling due to the evaporation causes too low measuring.

13 Fault and System Messages

Display	Meaning	Remedy
	Low battery voltage, device will continue to work for a short time If mains operation: wrong voltage	Replace battery Check/replace power supply, if fault continues to exist: device damaged
	Low battery voltage If mains operation: wrong voltage	Replace battery Check/replace power supply, if fault continues to exist device damaged
No display Or Weird display	Low battery voltage If mains operation: wrong voltage	Replace battery Check/replace power supply, if fault continues to exist device damaged
Device does not react on keypress	System error	Disconnect battery or power supply, wait some time, re-connect
	Device defective	Return to manufacturer for repair
----	Sensor error, no sensor connected	Connect sensor to socket
	Sensor/cable or device defective	Return to manufacturer for repair
Err.1	Value exceeding measuring range	Check: Is the value exceeding the measuring range? Temperature too high!
	Wrong probe connected	Check probe
	Sensor/cable defective	Replace
Err.2	Value below display range	Check: Is the value below the measuring range? Temperature too low!
	Wrong probe connected	Check probe
	Sensor/cable defective	Replace
Err.3	Value exceeding display range	Set resolution to 0.1° or Auto
Err.4	Value below display range	Set resolution to 0.1° or Auto
Err.7	System error	Return to manufacturer for repair

14 Reshipment and Disposal

14.1 Reshipment



GEFAHR

All devices returned to the manufacturer have to be free of any residual of measuring media and other hazardous substances. Measuring residuals at housing or sensor may be a risk for persons or environment



Use an adequate transport package for reshipment, especially for fully functional devices. Please make sure that the device is protected in the package by enough packing materials.

14.2 Disposal instructions



Batteries must not be disposed in the regular domestic waste but at the designated collecting points.



The device must not be disposed in the unsorted municipal waste! Send the device directly to us (sufficiently stamped), if it should be disposed. We will dispose the device appropriate and environmentally sound.

15 Specifications

Supported probes	Pt100 4-wires (2-wire possible)			
Sensor Curve	according to EN60751 or with user-sensor curve (table of 50 rows)			
Probe connection	4-pole Mini-DIN socket			
Resolution	0.01°C	0.1°C	0.01°F	0.1°F
Measuring Ranges	-199.99...199.99	-200.0...850.0	-199.99...199.99	-328.0...1562.0
Precision	Device without probe ±1Digit (at nominal temperature)			
Range 0.01°C/F	±0.03 °C / ±0.06 °F			
Range 0.1°C/F	±0.1 °C / ±0.2 °F			
Measuring	4-wire measuring with thermo-voltage compensation, measuring current 0.3 mA			
Measuring rate:	2 measurements per second			
Temperature influence	<= 0.002 K per 1K			
Nominal temperature	25 °C			
Ambient condition	-25 ... +50 °C (-13 ... +122 °F), 0 to 95 %RH (not condensing)			
Storage temperature	-25 ... +70 °C (-13...158 °F)			
Output:	3.5 mm audio plug, stereo output configurable to serial interface or to analog output			
serial interface:	via optically isolated interface adapter USB 3100, USB 3100 N, GRS 3100 or GRS 3105 (accessory) connectable to PCs with USB- or RS232-interfaces.			
analog output:	0..1V, freely scalable (resolution 13 bit, accuracy 0.05% at nominal temperature), cap. load < 1 nF			
Power Supply:	9V-Battery (included) as well as additional d.c. connector (diameter of internal pin 1.9 mm) for external 10.5-12V direct voltage supply. (Suitable power supply: GNG10/3000)			
Power Consumption	Output off	approx. 0.90 mA		
	Output = serial interface	approx. 1.15 mA		
	Analog output	approx. 1.25 mA		
Display:	Two 4 ½ digits LCD's (12.4mm and 7 mm high), additional segments			
Pushbuttons:	6 membrane keys			
Min-/Max-Memory	Both the max. and the min. value will be memorised.			
Holdfunction	Press button to store current value.			
Automatic-Off-Function	Device will be automatically switched off if not operated for longer time (adjustable from 1 ... 120 min)			
Min/Max-Alarm	The measuring value is constantly monitored for the min and max rails. Alarming is done by integrated horn, display and interface			
Real time clock	integrated clock with date and year			
Logger	2 Functions: individual value logger („Stor“) and cyclic logger („Cycl)			
Memory	Stor: 99; Cycl: 16384			
Cycle-time CYCL	0:01 ... 60:00 (minutes/seconds, min 1s, max 1h)			
Housing:	impact-resistant ABS plastic housing, membrane keyboard, transparent panel. Front side IP65, integrated pop-up clip for table top or suspended use.			
Dimensions:	142 x 71 x 26 mm (L x B x D)			
Weight:	approx. 155 g			
Directives / standards:	The instruments confirm to following European Directives:			
	2014/30/EU EMC Directive			
	2011/65/EU RoHS			
	Applied harmonized standards:			
	EN 61326-1 : 2013 emissions level: class B, emi immunity acc. to table 3 and A.1 Additional fault: <1%			
	EN 50581 : 2012			